

Ein-Ausgang

13

12

11

10

9

8

7

6

5

4

3

2

1



14

15

16

17

18

19

20



41

40

39

38

37

36

35

34

42


43

44

45

46

47



31

32

33



30a

30

29

28



21

22

23

24

25

26

27



Ein-Ausfahrt